Attachment A Required Maintenance for HVAC Equipment Water Department Meter Shop March 17, 2008

A. Boiler

- 1. Clean fireside surfaces and flueways.
- 2. Provide chemical treatment of hot water system on an annual basis
- 3. Check pressure relief valve

B. B&G Circulating Pumps

1. Lubricate pump and motor bearings

C. Unit Heaters

1. Lubricate motor sleeve bearings

D. Trane Co. Cabinet Heaters

- 1. Check air filters. Replace if dirty
- 2. Lubricate fan motor.
- 3. Clean unit casing.
- 4. Inspect fan blades and housing. Clean if dirty.
- 5. Clean coils and vacuum fins.

E. Wall Fin Radiation

- 1. Clean enclosures and vacuum fins.
- 2. Length of Fin Tube Radiators located in the office area is approximately 100'.

F. Trane Co. Air Handling Units

- 1. Inspect air filters. Replace if clogged.
- 2. Lubricate fan bearings and fan motors.
- 3. Check fan belt tension. Replace worn belts with a new matched set
- 4. Inspect coils. Clean fins if cloqged.
- 5. Inspect wiring and tighten all connections.
- 6. Clean unit casing, fan wheels and fan shaft.
- 7. Inspect drain pan. Clear drain openings and drain lines.
- 8. Check damper linkages, setscrews and blade adjustment for proper tightness and operation.

G. Condensing Units

- 1. Inspect evaporator and condenser coils.
- 2. Clean coils following manufacturer's recommendations.
- 3. Inspect evaporator coil air filters. Replace as needed.
- 4. Check fan belts and tighten if needed. Replace if worn.
- 5. Check electrical controls. Make sure all connections are tight.

H. Gas Furnace

- 1. Inspect burner and flame. Clean any dirt.
- 2. Check for gas leaks
- 3. Inspect heat exchanger for leaks, corrosion, carbon deposits.

I. Gas-Fired Make-Up Air Units

- 1. Inspect burner and flame. Clean any dirt.
- 2. Check for gas leaks.
- 3. Clean fans and wheels.
- 4. Check air filters. Replace if dirty.
- 5. Lubricate if necessary.
- 6. Adjust tension on fan belts. Replace if worn.

J. Co-Ray-Vac Radiant Heating System

- 1. Check for gas leaks. Check operation of (11) burners.
- 2. Check operation of (2) vacuum pumps.

K. Exhaust Fans

- 1. Adjust tension on fan belts. Replace if worn.
- 2. Lubricate where necessary.

L. VAV Box: Provide preventative maintenance – Cooling Only

M. Purafil Deodorizing Filter System

- 1. System consists of 8 (charcoal) odor filters
- 2. Replacement of the charcoal (approximately 160 lbs) shall be done on an as needed basis (approximately every 12 to 18 months)
- System is located in the Northeast corner of the ceiling in the boiler room.